

HOW TO CLEAN

1

Remove the atomizer and downstem

2

Clean with a cotton bud/brush remove isopropyl alcohol.



MADE IN CHINA
www.lookah.com
ORIGINAL DESIGN BY LOOKAH



LOOKAH®
ORIGINAL DESIGN ONLY

USER MANUAL V1.0



PRODUCT OVERVIEW

SUITABLE FOR 710 SERIES



Coil is consumable, so please replace it after using for a while.

FEATURES

1. Replaceable and multiple coil choices.
2. The built-in display screen shows the battery charge and voltage setting.
3. Three mode voltage adjustment to meet different needs.
4. Magnetic flip cap that is easy to use
5. Battery Capacity: 950MAH
6. Charging current: 380MA
7. Charging input voltage: USB 5V

HOW TO USE

1. Open the magnetic flip cap and put the material into the chamber.
2. Press the power button 5 times within 2 seconds to turn on the device. The battery indicator flashes 3 times and then the device starts automatic preheating and displays a countdown like "9, 8, 7---0" on the screen. The preheating lasts 10 seconds, which can be stopped by pressing the button once. After the preheating done, the battery light will flash 2 times, and the device enters the current voltage setting.

CHANGE VOLTAGE

3. To change the voltage press the power button 2 times within 0.8 seconds :
green>blue>white>green.

Mode 1: Green—3.2V

Mode 2: Blue—3.6V

Mode 3: White—4.0V

MANUAL MODE

1. Press and hold the button to start working, (Continue to hold the power button for up to 30s). After 30s the device will stop heating, the indicator light will flash 5 times and the device will enter standby.
2. Turn off: Press the button 5 times within 2s to turn off the device. (The indicator light will flash 3 times.)
3. The device will automatically turn off if there is no operation for 60 minutes.

Caution: It can damage the coil or the device if it is used without material in the coil chamber.

ALARMS INDICATIONS

1. Low battery alarm: "L" is displayed. The red light flashes 5 times and the device vibrates. Please charge the device before use.

2. High temperature alarm: "H" is displayed. The purple light flashes 5 times and the device vibrates. Please let the device cool down before use.
3. Short-circuit alarm: "0" is displayed. The yellow light flashes 8 times and the device vibrates. Please replace the atomizing core before use.
4. Open-circuit alarm: "9" is displayed. The yellow light flashes 5 times and the device vibrates. Please replace the atomizing core before use.

CHARGING

1. Battery is charging: When Charging: The battery LED indicator bars will flash counterclockwise in scrolling form and the red LED light will be on.
2. Battery is fully charged: The battery LED will remain on with all bars lit while the USB cable is connected and the cyan LED light will be on.

NOTES

1. This device is a high-temperature product, it is normal that the housing becomes moderately heated during use.
2. If the housing gets too hot to touch by hand during use, please stop using the device, turn it off and allow it to cool down.

KIND REMINDER

For better understanding and use of this device, please carefully read this manual prior to the first use.

1. This product is not intended for use by persons under 21 years old, women who are pregnant or breastfeeding, or persons with or at risk of heart disease, high blood pressure, diabetes, or persons taking medicine for depression or asthma
2. Battery built-in the device. Please do not expose the device to high temperature, cold or humid environment.
3. Do not expose the device to water.
4. Turn off the device when not in use.

WARRANTY

30 days from the date of purchase against manufacture defects. Does not apply to improper use. Used consumables are not covered by the warranty.